


How To Remove The Outer Shell Of The Vetrano 2B

1.



2.




3.



4.



5.



6.

